



Routine Cleaning Instructions for Massage Chair

1. Daily Cleaning (After each use / Daily)

Wipe off dust, sweat and hair from the surface with a dry soft cloth.

Focus on: armrests, backrest, leg rest, controller.

2. Deep Cleaning (Once a week)

Wipe the PU leather / genuine leather surface with a slightly damp soft cloth (wring until no water drips).

Neutral cleaner / leather cleaner is allowed. Do **not** use alcohol, 84 disinfectant, bleach or thinner.

Remove hair and debris in gaps with a small brush / crevice tool or vacuum cleaner.

3. Airbags & Rails (Once a month)

Airbag surface: gently wipe with a damp cloth.

Mechanical rails: do **not** apply oil or spray water; keep clean and dry.

4. Fabric / Mesh Parts

Vacuum to remove dust.

For light stains: gently pat with a damp cloth. Do **not** rub vigorously.

Do not rinse with plenty of water.

Important Notes

Never spray, pour or flush water inside the massage chair.

Unplug the power before cleaning.

Avoid long-term direct sunlight to prevent leather cracking.

Do **not** use cleaners containing solvents, strong acids or alkalis.